


# LDM-AEZ Series User's Manual

Ultra precision vertical stages



## Disclaimer

Zaber's products are not intended for use in any critical medical, aviation, or military applications or situations where a product's use or failure could cause personal injury, death, or damage to property. Zaber disclaims any warranty of fitness for a particular purpose. The user of this product agrees to [Zaber's general terms and conditions of sale](#).

## Precautions

Zaber's autodetect peripheral axes are designed to be used effortlessly with Zaber's line of autodetect controllers. The LDM-AEZ includes onboard memory that allows Zaber's controllers to autodetect the model and set reasonable parameters. See the [Protocol Manual](#) for more information on how to modify the settings. Damage to the axis may result if the settings are not correct. To use your Zaber peripheral with a third-party controller, review the motor, sensor, and encoder specifications and pin-outs carefully.

Contamination could impact the performance of the LDM-AEZ stage. Avoid introduction of ferro-magnetic particles to the stage, and contact with, or contamination of, the encoder scale.

## Important Precautions for Use

**⚠ Mounting and Maintenance Hazard!** For operator safety, the LDM-AEZ should always be un-powered during all cleaning, maintenance, and stage or load mounting operations. A powered stage could exert high forces and move at high speeds very suddenly if accidentally given a move command.

**⚠⚠ Strong Magnets!** The LDM-AEZ stages contain strong magnets that could affect pacemaker function. Pacemaker users should stay at least 20 cm away from the stages. The magnets can also attract nearby magnetic objects.

**⚠ Secure Stage Mounting Required!** The LDM-AEZ stages can shake and vibrate during operation due to high inertia. The stages must always be securely mounted to a work surface during operation. See [#Physical\\_Installation](#) for information on stage mounting.

**⚠ Back-driving Hazard!** Linear motor stages require current to the motor coils to provide a force to maintain position and/or support a load. If power is removed the carriage may move suddenly or in an uncontrolled manner. The LDM-AEZ stage is not intended for load lifting operations due to the risk of uncontrolled motion if driver power is removed.

**⚠ Collision Hazard!** Provide a safe distance around the stage and its load to allow for unobstructed full travel movements between travel end-stop bumpers. Ensure that a positional overshoot or unexpected motion couldn't result in a collision hazard.

**💡 Important:** The LDM-AEZ stage should be homed immediately upon power-up.

**💡 Important:** The LDM-AEZ is a servo device, meaning that its performance is dependent on proper tuning of the servo parameters for the given load. The use of incorrect servo parameters may reduce the device's performance in operation. Incorrect tuning may also result in unstable operation, which can cause unexpected rapid motion of the device, leading to reduced device lifetime and user injury. When the operating load on the device is changed, the tuning parameters should be updated to match. For details see the servo tuning guidelines.

## Noise Emissions

The A-weighted emission sound pressure level (SPL) of this device does not exceed 70 dB(A) during intended use.

## Conventions used throughout this document

- Fixed width type indicates communication to and from a device. The  $\mu$  symbol indicates a carriage return, which can be achieved by pressing enter when using a terminal program.

## Device Overview

### AutoDetect

Your LDM-AEZ peripheral is equipped with AutoDetect, a feature that allows a Zaber controller to automatically configure its settings for the peripheral when it is connected.

**⚠ Important:** The controller should always be powered down before disconnecting or connecting your LDM-AEZ peripheral.

To connect the peripheral to a controller:

- Power off the controller.
- Connect the LDM-AEZ peripheral.
- Power on the controller.
- The controller will activate the peripheral shortly after it is powered on.

See the Zaber controller user manual for more details on peripheral activation and control.


### Connectors

Recommended controller(s) for your LDM-AEZ peripheral are provided in the product specifications. Zaber's controllers and peripherals are designed for ease of use when used together. Optimal settings for each peripheral are automatically detected by Zaber's controllers when the device is connected.

For reference, the pinout for the peripheral cable connectors is shown below:

#### Pinout for D-sub 26 Connectors (peripherals)

Pin	Description	Pin	Description
1	AutoDetect Clock	14	Motor Hall C
2	AutoDetect Data	15	+5V
3	N.C.	16	Ground
4	N.C.	17	N.C.
5	N.C.	18	Motor W
6	Motor Over-Temperature	19	Differential Encoder A-
7	Ground	20	Differential Encoder B-
8	Motor V	21	Differential Encoder Index-
9	Motor U	22	Motor Hall A
10	Differential Encoder A+	23	Motor Hall B
11	Differential Encoder B+	24	N.C.
12	Differential Encoder Index+	25	N.C.
13	Differential Encoder Error	26	N.C.



Male High Density D-sub26 Connector  
Motor and Sensor Interface

**NOTE:** All hall sensor signals (for limits or motor phase) are open collector and require a pull-up on the controller.

**NOTE:** All single-ended encoder inputs are non-isolated 5V TTL lines.

**NOTE:** All differential encoder signals are non-isolated, and must be terminated on the controller with 120  $\Omega$ . For -AE peripherals, these signals are sinusoidal with 1 V peak-to-peak differential levels and with the common mode between 1.5 V and 2.5 V.

## Alternate Controllers

The LDM-AEZ can be controlled by other linear motor controllers with appropriate encoder input. **We do not recommend using your own controller unless you are familiar with wiring and tuning third-party linear motor products.** Damage to the device due to incorrect wiring is not covered by warranty.

## Motors & Encoders

For motor and encoder information see the [LDM-AEZ product page](#)

## Installation


The LDM-AEZ can be operated by connecting to the controller/s recommended in the product specifications. Please review the controller's user manual as well.

## Physical Installation


**⚠ Mounting and Maintenance Hazard!** For operator safety, the LDM-AEZ should always be un-powered during all cleaning, maintenance, and stage or load mounting operations. A powered stage could exert high forces and move at high speeds very suddenly if accidentally given a move command.

## Unpacking & Handling


LDM-AEZ stages are shipped with a red plastic travel lock designed to restrict motion of the stage during transport. This lock must be removed prior to mounting the stage.



Compress the counterbalance by applying force to the carriage as shown while holding the base stationary. Up to 40N (9lb) of force may be required to compress the counterbalance.



While compressing the counterbalance, remove the travel lock out the side. Retain this part for future use.



Slowly release the force applied to the stage. The counterbalance will push the carriage to the top end of travel.

## Mounting

💡 **Tip:** To obtain the best pitch, roll, yaw and runout performance, mount the stage to a known flat, stiff surface. Our tests were performed on a granite surface plate, grade A flatness.


⚠️ **Stability Hazard!** Ensure the stage is fastened to a secure surface before mounting a load on the carriage. Ensure loads are mounted securely to the carriage of the stage before operating.

LDM-AEZ stages are designed to be secured using 4 metric or imperial socket cap screws. The following screw sizes should be used:

- Metric: M6 screws, 25mm or longer
- Imperial: 1/4 screws, 1" or longer



The stage must be mounted with a specific end facing upwards. The upwards direction is indicated by an arrow on the side of the counterbalance.




Manually move the stage to its travel limits to access the mounting holes.

## Counterbalance Adjustment


LDM-AEZ stages feature a passive adjustable magnetic counterbalance. The counterbalance force output should be adjusted to neutrally balance whatever payload weight is mounted to the stage. Proper adjustment of the counterbalance will ensure that the stage does not move unexpectedly if power is lost.




Remove power from the stage or send a [driver disable](#) command to disable the motor.




Mount the desired payload to the stage using the M6 mounting holes.



The counterbalance force is indicated on the side of the stage. It may be necessary to add extra payload mass to the stage if the counterbalance's minimum force is greater than the payload weight.



Adjust the counterbalance force by rotating the 4mm hex screw on top of the counterbalance. The screw will be easiest to adjust with the stage near its topmost position. Adjust the force until the payload is neutrally balanced.



The adjustment screw may begin to unthread when decreasing the force. If the force indicator does not display minimum force, manually move the stage through its travel range to decrease the counterbalance force.



With the payload neutrally balanced, power up the stage or send a [driver enable](#) command to re-enable the motor.

## Servo Tuning

This peripheral is a closed-loop positioning servo system. It continuously monitors and corrects its position via the linear encoder. As with any servo system, the behaviour is dependent on the controller tuning. The LDM-AEZ, when paired with a compatible Zaber controller, such as an X-MCC series Universal Motor Controller, will be appropriately tuned out of the box with settings that are optimized for regular use under a light load. However, as with any closed-loop feedback system, the device performance is load-dependent, and conditions significantly outside of the intended operating range have the potential for reduced performance or instability. Thus, if operation with large or unconventional dynamic loads is desired, or if the application demands specific performance characteristics, it may be necessary to tune the servo parameters. This may be conveniently done by using Zaber Launcher's Servo Tuner App, or [Zaber Motion Library's ServoTuner API](#).

**Tip:** Because servo devices continuously monitor and correct position, it is necessary to specify how accurate and stable the final position must be at the end of the movement. Criteria required for the controller to report IDLE status after movement are specified using the [cloop.settle.tolerance](#) and [cloop.settle.period](#) settings. For applications requiring utmost precision, you may want to specify a smaller tolerance and longer period. Note that there is a direct, inverse relationship between settling time and [cloop.settle.tolerance](#), and the controller may never report IDLE status if the tolerance is too small.


## Lubrication and Cleaning

LDM-AEZ devices use cross roller bearing linear guides to support and guide the stage top of the device. These linear guides require lubrication in order to achieve the longest possible lifetime at the highest possible performance. For operation in clean environments, it is recommended to lubricate the linear guides annually or every 500km, whichever comes first. For applications in dirty environments or applications with extremely high duty cycles, more frequent inspection and lubrication is recommended. For longest lubrication intervals, we recommend lubricating guides with Kluberplex BEM 34-132 grease. All guides come pre-lubricated and are ready to go out of the box.


If LDM-AEZ devices are used in applications where only a small portion of the travel range is used, it is recommended to occasionally drive the stage throughout its full travel range to maintain an even lubrication film over the entire guide surface.



Remove power to the device before attempting to lubricate.



1. Manually move the stage to a travel limit to expose the linear guides.
2. Using a lint free cloth, wipe away any old grease and debris on the v-channels of the guides. Wipe towards the outside of the stage so debris is not pushed into the roller bearings.
3. Apply a thin strip of lubricant over the entire exposed length of the v-channels with a syringe.
4. Manually move the stage to the opposite travel limit and repeat steps 2 and 3 on the opposite side.



Manually cycle the stage throughout its full travel range a few times to evenly distribute the lubricant. Wipe away any excess lubricant.

## Trajectory Control and Behaviour

This section describes the behaviour of the axis trajectory when a movement command is issued.

### Software Position Limits

The travel range of the axis is limited by the Minimum Position and Maximum Position settings. The factory settings for the axis are configured to match the physical travel range. If a customized range is desired, it can be changed by configuring the [limit.min](#) and [limit.max](#) settings to appropriate values. For the Current Position, query [pos](#).

#### Minimum Position

When the Current Position is less than the Minimum Position value, the axis cannot move in the negative direction.

#### Maximum Position

When the Current Position is greater than the Maximum Position value, the axis cannot move in the positive direction.

### Movement Speed

The movement speed of the axis depends on axis status and various speed settings. If the axis has not been initialized by the [home](#) command or by moving towards the home end of the axis, movement speed will be constrained to fail-safe values. The home status of the axis can be determined by reading the [limit.home.triggered](#) setting.

Movement speed of the axis is specified below:

#### [move vel](#)

The axis will move at the specified speed regardless of home status.

#### Knob movement in Velocity Mode

The axis will move at the specified speed regardless of home status.

The speed is specified by the [knob.speedprofile](#) and [knob.maxspeed](#) settings.

#### Other movement commands - when the axis has not been homed

The axis will move at the slower of the [maxspeed](#) and [limit.approach.maxspeed](#) settings.

#### Other movement commands - when the axis has been homed

The axis will move at the speed specified by the [maxspeed](#) setting.

## Warranty and Repair

For Zaber's policies on warranty and repair, please refer to the [Ordering Policies](#).

### Standard products

Standard products are any part numbers that do not contain the suffix ENG followed by a 4 digit number. Most, but not all, standard products are listed for sale on our website. All standard Zaber products are backed by a one-month satisfaction guarantee. If you are not satisfied with your purchase, we will refund your payment minus any shipping charges. Goods must be in brand new saleable condition with no marks. Zaber products are guaranteed for one year. During this period Zaber will repair any products with faults due to manufacturing defects, free of charge.

## Custom products

Custom products are any part numbers containing the suffix ENG followed by a 4 digit number. Each of these products has been designed for a custom application for a particular customer. Custom products are guaranteed for one year, unless explicitly stated otherwise. During this period Zaber will repair any products with faults due to manufacturing defects, free of charge.

## How to return products

Customers with devices in need of return or repair should contact Zaber to obtain an RMA form which must be filled out and sent back to us to receive an RMA number. The RMA form contains instructions for packing and returning the device. The specified RMA number must be included on the shipment to ensure timely processing.

## Email Updates

If you would like to receive our periodic email newsletter including product updates and promotions.

## Contact Information

Contact Zaber Technologies Inc by any of the following methods:

<b>Phone</b>	1-604-569-3780 (direct) 1-888-276-8033 (toll free in North America)
<b>Fax</b>	1-604-648-8033
<b>Mail</b>	#2 - 605 West Kent Ave. N., Vancouver, British Columbia, Canada, V6P 6T7
<b>Web</b>	<a href="http://www.zaber.com">www.zaber.com</a>
<b>Email</b>	Please visit our website for up to date email contact information.

The original instructions for this product are available at <https://www.zaber.com/manuals/LDM-AEZ>.


## Appendix A: Default Settings

Please see [the Zaber Support Page](#) for default settings for this device.

# Product Drawing


# ZABER

LDM-AEZ Direct Drive Vertical Stage  
dimensions in mm



Model Number*	Nominal Travel	Hard Stop Travel
LDM040C-AE54ZJ2T10A	40.0	50.0
LDM060C-AE54ZJ1T10A	60.0	76.0

\*See product page for complete list of available models at [www.zaber.com](http://www.zaber.com)



DWG 3764 R01D

## Specifications


Specification	Value	Alternate Unit
Built-in Controller	No	
Recommended Controller	X-MCC (48 V) Recommended	
AutoDetect	Yes	
Accuracy (unidirectional)	1 $\mu$ m	0.000039"
Repeatability	< 0.08 $\mu$ m	< 0.000003"
Minimum Incremental Move	8 nm	
Minimum Speed	0.61 nm/s	
Speed Resolution	0.61 nm/s	
Encoder Type	Linear analog encoder	
Encoder Count Size	1 nm	
Peak Thrust	90 N	20.2 lb
Maximum Continuous Thrust	25 N	5.6 lb
Maximum Moment (Pitch)	1200 N-cm	1699.3 oz-in
Maximum Moment (Roll)	1200 N-cm	1699.3 oz-in
Maximum Moment (Yaw)	1200 N-cm	1699.3 oz-in
Horizontal Runout	< 4 $\mu$ m	< 0.000157"
Pitch	0.003°	0.052 mrad

Specification	Value	Alternate Unit
Roll	0.002°	0.035 mrad
Yaw	0.002°	0.035 mrad
Counterbalance Type	Adjustable Magnetic	
Motor Type	Moving Magnet Track Linear Motor	
Motor Rated Current	2400 mA/phase	
Force Constant	15.8 N/A	3.5 lbs/A
Motor Winding Resistance	6.4 ohms/phase	
Inductance	1.24 mH/phase	
Motor Connection	D-sub 26	
Guide Type	Crossed-Roller Bearing	
Limit or Home Sensing	Optical Index Mark	
Axes of Motion	1	
Mounting Interface	M6 threaded holes	
Moving Mass	2.32 kg	5.104 lbs
Operating Temperature Range	0 to 50 °C	
CE Compliant	Yes	
Vacuum Compatible	No	
Weight	5.14 kg	11.332 lb


## Comparison

Part Number	Travel Range	Maximum Acceleration	Maximum Speed	Counterbalance Payload Range
<b>LDM040C-AE54ZJ2T10A</b>	40 mm (1.575")	9 m/s <sup>2</sup> (0.92 g)	600 mm/s (23.622"/s)	38-55 N (8.5-12.3 lb)
<b>LDM060C-AE54ZJ1T10A</b>	60 mm (2.362")	16 m/s <sup>2</sup> (1.63 g)	800 mm/s (31.496"/s)	10-33 N (2.2-7.4 lb)

### Typical Accuracy



## Typical Minimum Incremental Move



## Product Change Notices

Click [here](#) to view the current product change notices and subscribe to future change notifications.